



PURKEYS

**P/N P808-1022FC
INVERTER HARNESS
INSTALLATION GUIDE**

Doc 1.01
INST085

STEP 1

The inverter will be mounted behind the driver's seat on the side of the cabinet. Mount the inverter with self-drilling screws and connect the chassis ground.

**STEP 2**

The cable pass through flange will be located between the battery disconnect and seat belt, this hole must be drilled in front of the seat belt mounting point. (This is to avoid the cross member under the floor)

Note: Be sure and verify there is nothing under this location that could be damaged when the hole is drilled. There is a possibility an air-line is under the mat.

**STEP 3**

Attach the input cables to the inverter and install the plastic post protectors. Route cables and chassis ground to the pass through flange and push cables through flange

NOTE: Be sure to observe the polarity, reversing these connections will cause major damage to the inverter.



STEP 4

Attach the chassis ground cable to a cross member using a self-drilling screw. Route the 1/0 cables to the battery box. Securing as needed with zip ties and clamps.

**STEP 5**

Route cables to the battery box. Install the 150 amp fuse cube to positive terminal of the battery. Install 1/0 red cable on fuse cube and tighten the nut.

**STEP 6**

Install 1/0 black cable on negative side of battery.

NOTE: Due to the electronics used in inverters it is not uncommon for there to be a large spark when the last connection is made.



REQUIRED INSTALLATION TOOLS

- Electric or cordless drill
- 3 1/2" hole saw and arbor
- 5/16 socket and holder for drill
- 7/16 wrench or socket
- 9/16 wrench or socket
- 13mm wrench or socket
- Channel locks

LIMITED COMMERCIAL WARRANTY POLICY

Purkeys Fleet Electric, Inc. (hereafter "Purkeys"), warrants each product to be free of defects in material or workmanship under normal use and service. This warranty is for the benefit of Original Equipment Manufacturers, Dealers, Warehouse Distributors, Fleets, or other End Users (hereafter "Customers") and covers products manufactured by Purkeys and sold new to Customers either directly by Purkeys or by its authorized dealers, distributors, or agents. The length of the Warranty Period is 24 months.

The warranty period commences on the in-service or install date and is not transferable. Failure to provide the in-service or install date on the warranty claim form will cause the warranty period to begin on the date the part was manufactured or date of sale recorded on the original sales invoice, whichever is earlier.

A completed warranty claim form should accompany all parts submitted to Purkeys for consideration for repair or replacement under warranty. The submitted claim form should contain all of the information required. Lack of a properly or fully completed claim form will result in delay or denial of warranty claim. Claims must be submitted no later than 30 days after part is removed.

This warranty does not apply if, in sole judgement of Purkeys, the product has been damaged or subjected to accident, faulty repair, improper adjustment, improper installation or wiring, neglect, misuse, or alteration or if the product failure is caused by defects in peripheral vehicle components or components attached to the Product or failure of a part not manufactured by Purkeys.

This warranty shall not apply if any Purkeys product is used for a purpose for which it is not designed or is in any way altered without the specific prior written consent of Purkeys. ANY Product alleged by a Customer to be defective must be inspected by Purkeys as a part of the warranty claims process in order to confirm that the part has failed as a result of a defect in material or workmanship.

Transportation for products and parts submitted to Purkeys for warranty consideration must be prepaid by Customer. Repaired or replaced products and or components will be returned to Customer pre-paid by Customer or "freight collect" to the address provided by Customer in the warranty claim form. No charge will be made for labor or material in effecting such repairs.

The Warranty provided by Purkeys hereunder is specifically limited to repair or replacement of the Product as Purkeys deems most appropriate in its sole discretion. Purkeys neither assumes nor authorizes any other person to assume on its behalf any other warranty or liabilities in connection with Purkeys products. The Warranty does not apply to fuses or other "consumable" or maintenance items which are or may be a part of any Purkeys product.

THIS WARRANTY DOES NOT APPLY TO LOSS OF VEHICLE OR EQUIPMENT, LOSS OF TIME, INCONVENIENCE, OR OTHER INCIDENTAL OR CONSEQUENTIAL DAMAGES. PURKEYS SPECIFICALLY DISCLAIMS AND SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES arising out of or from the use of Purkeys products by the Customer.

THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, INCLUDING COMMON LAW WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, AND ANY OTHER EXPRESS OR IMPLIED WARRANTIES. ALL OTHER SUCH WARRANTIES ARE SPECIFICALLY DISCLAIMED.

This Limited Commercial Warranty supersedes all previous Warranty Policies issued by Purkeys and any of its suppliers.